

MODEL 184
SERIES A3

Index No.	Description	Part No.	Qty.
1	Dome, Red	8434D101-01	1AR
	Dome, Blue	8434D101-02	
	Dome, Amber	8434D101-04	
	Dome, Clear	8434D101-05	
	Split Dome, Red and Blue	8434C102-01	
	Split Dome, Red and Clear	8434C102-03	
	Split Dome, Amber and Red	8434C102-04	
2	Retaining Band Assembly	8424C010	1
3	Brush Holder and Lamp Assy. (consists of Items 5, 3C (2), and 3D which includes 3A and 3B)	8424A049	2
3A	Spring	8240A032	2
3B	Brush	8240A031-01	2
3C	Lamp Holder	8424B012	4 or
3D	Brush Holder and Contact Spring Assy. (includes items 3A and 3B)	8424A006	2
4	Lamp, 6-volt, clear (GE #4516)	8107A032	4AR
	Lamp, 12-volt, clear (GE #4416)	8107A033	
	Lamp, 12-volt, blue (GE #4416B)	8107A057	
	Lamp, 12-volt, amber (GE #4416A)	8107A059	
	Lamp, 12-volt, red (GE #4416R)	8107A042	
	Lamp, 24-volt, clear (GE #4505)	8107A027	
5	Lamp Clamp Wire	8422B016	4
6	Shaft	8424A004	1
7	Retaining Ring	8422A010	2
8	3/8" Washer	7072A139	1
9	Bearing, Upper	8240A034-01	1
10	Collector Ring Assembly	8424A002	1
11	Housing (standard height)	8424C055A-01	1AR
	Housing (extra high for Model 184H)	8424C055A-02	
12	Base Plate	8240B139-02	1
13	Bearing Support	8424A014	1
14	Worm Gear and Clutch Assy.	8422A114	1
15	Bearing Lower	8240A034-02	1
16	Bearing Support	8240A009	1
17	Gear Box	8240C008	1
18	Gear Box Cover	8240B010	1
19	Filter, 24-volt	8226A186	1AR
20	Insulator	8240A130	1
21	Terminal	8240A021	1
22	Motor Adapter Plate Assy.	8240A631	1
23	Motor, 6-volt	8240A420-07	1AR
	Motor, 12-volt	8425A058A	
	Motor, 24-volt	8240A420-24	
Not Shown	Switch	8240A033	1
	Toggle Bolt	8240A041	3 Long
	Skirt Gasket, Bottom	8240A007-01	1
	Ground Strap for toggle bolt	8240A023	1
	Tapered Rubber Washer	8240A022	6
	Grommet (used for mounting)	8108A005	1
	Motor Plate Adaptor (12 Volt only)	8424A057	1AR


8424C052

8424A015

Mounting Kit

8424A017-01

MODEL 184
SERIES A3



4 Motor Screws

7000A251-05